GENERAL NOTES:

Use 5-minute Epoxy or cyanoacrylate (Super Glue) for assembly

Lay out all parts and familiarize yourself with their location before assembly and dry fit all parts before gluing and painting.

Clean mold marks from castings using a #11 or #12 hobby knife, small files and sandpaper. Be careful not to make scratches across the wheel tires. If you intend to leave this area unpainted, polish the tires with steel wool and coat with clear lacquer.

In cleaning the castings, be careful not to destroy or damage the wood grain effect. If you inadvertantly do so, you can re-establish the effect by drawing the edge of a file or riffler across the casting in the same direction as the existing wood grain.

Clear all holes with a sharp instrument or drill.

ASSEMBLY:

- (1) Assemble FRONT and BACK of the AMMUNITION CHEST to the ENDS, noting tops and bottoms from illustration. Check for squareness and attach BOTTOM so that its end straps fit the recesses in the bottoms of the ENDS. Attach the HANDLES on the ENDS.
- (2) Assemble PINTLE HOOK (Trail Hitch) to the recess in the AXEL HOUSING.
- (3) Begin the CARRIAGE assembly by gluing the SPLINTER BAR (TREE) to the HOUND and FORK casting.
- (4) Attach the FRONT FOOT BOARD. Note that it slants to the rear.
- (5) Glue on the FORK STRAP.
- (6) Attach the AXEL HOUSING to the HOUND AND FORK casting, PINTLE HOOK to the rear.

- (7) Fit UNDER STRAPS over the AXEL HOUSING directly in line with the HOUNDS. CHAIN STUD on RIGHT STRAP goes to the rear, on LEFT STRAP to the front.
- (8) Install MID BANDS into recess in FORKS, with flat under SPLINTER BAR.
- (9) Install END BANDS to SPLINTER BAR ends with loop facing forward.
- (10) Slide POLE between FORKS until it butts against the back stop. Mark location of the BUCKET HOOK, remove POLE and cut a notch for the BUCKET HOOK strap end.
- (11) Cut the POLE to 8" long, then sand it round from the front end for a distance of 5". Note that it must fit the MUFF & COLLAR at 1 1/8" from the front end and the PAD on the end.



- (12) Slide the POLE back between FORKS and lock in place with the BUCKET HOOK.
- (13) Slip YOKE BRANCHES onto pivots on MUFF & COLLAR and squeeze the pivots to lock the BRANCHES so they are movable.
- (14) Glue step 13 assembly onto POLE, 1 1/8" from the end with BRANCHES level and curved forward.
- (15) Attach SLIDING RINGS to BRANCHES by crimping hooks.
- (16) Glue POLE PAD to front end of POLE.

(17) Insert POLE STRAP (IRON) EYELET RINGS through slot in POLE STRAPS and glue these in place, right and left, immediately behind the PAD. Attach the split-ring EYELETS to RINGS as shown.

- (18) The TRACE HOOKS (s-hooks) mist be twisted so the loops are at right angles instead of flat. Cut two 1 1/2" lengths of chain and attack each end to a TRACE HOOK. For each chain, attach one TRACE HOOK to an END BAND and the other to a MID BAND.
- (19) Cut a 3" length of chain for the LOCK CHAIN. Spread one link, double it back on itself as shown and close the link. Glue the free end to the stud under the left HOUND and the other "end" to the stud on the LEFT UNDER STRAP.
- (20) Cut two 1" lengths of chain and glue one end of each to the stud on the outside rear of the HOUNDS and the other to the bottom of

the rear CHEST STRAPS. You may want to drill into the cast bolt head and insert a pin to facilitate this.

- (21) Attach 1 1/4" of chain to the PINTLE KEY and the other end to the stud on the right UNDER STRAP.
- (22) By spreading then crimping the ends, attach 1" of chain to the POLE PROP and one of the TRACE HOOKS on the FORK.
- (23) Assemble the BUCKET as shown and hang from the BUCKET HOOK.
- (24) To display the model with the POLE PROP in use, glue it into the hole under the SPLINTER BAR. To display with the PROP stowed, hang it between the left chain under the SPLINTER BAR and the LOCK CHAIN.
- (25) Paint WHEELS to match carriage, with HUB BANDS and tire BOLTS black. Slide WHEELS (narrower hubs facing out) over AXELS. Secure with HUB CAPS & FIDS.


COLORS:

Paint the LIMBER light gray or olive drab, but, if displayed with one of our Civil War gun kits, use the same scheme for both. The exact shade would vary according to circumstances. Most batteries painted metal parts, marked with an "X" on the drawing, black.

This model is derived from the original Marine Model Company kit and has been updated by Model Shipways Inc. and Ken Goldman.



Manufactured by Model Shipways, Inc. Sold & distributed by Model Expo Hollywood, Florida USA www.modelexpo-online.com



AMERICAN CIVIL WAR LIMBER PARTS LISTS MS4002

PART#	ITEM	QUANTITY	DESCRIPTION/NOTES
BRITANNIA CASTINGS			
WP0001 WP0002 WP0003 WP0004 WP0005	Bucket Bucket handle Top Muff & Collar Mid Band	1 1 1 1 2	
WP0006 WP0007 WP0008 WP0009 WP0011	Ring Branch Iron Pad End Band	2 2 2 1 2	
WP0012 WP0013 WP0014 WP0015 WP0016	Sliding Ring Front foot board Pole prop Pintle hook Trace hook	2 1 1 1 4	
WP0010 WP0017	Under Strap Fork strap	2 1	
WP0018 WP0019 WP0020	Key Bucket hook Chest handle	1 1 2	
WP0021 WP0022	Cap & fid Wheels	2 2	
WP0023 WP0024 WP0025 WP0026 WP0027	Hounds Chest Lid Chest Bottom Chest Rear Chest Front	1 1 1 1 1	
WP0028 WP0029 WP0030	Chest End/Corner plate Tree Axle	2 1 1	
MISCELLANEOUS FITTINGS AND MATERIAL			
WP0954 WP2800 WP3640-24	Eyelet Chain Wood Pole 3/16x3/16	2 10" 12"	
INSTRUCTIONS			
WPPL4002 WP4002MB	Parts List Instructions		