

ASSEMBLY INSTRUCTIONS

This LOW RELIEF model has been designed for use against a straight, curved (either concave or convex), or angled background and can be realistically illuminated from behind.

Separate parts as required by nicking with a knife at uncut points with the exception of those cutter lines marked with red arrows. Lines so marked must not be cut right through as the model is designed to be bent back at an angle along these lines. Most liquid glues are suitable adhesives, but a P.V.A. white glue is particularly recommended. The spare board supplied can be used for pavements etc., or, if the buildings are preferred as separate units, as material for completing the side walls.

1 Separate the "NORWICH UNION" Wall and remove the waste pieces from the door and window apertures. For the best finish, the edges so exposed should be coloured with water colour paint mixed to an approximate match. Draw the knife down the scored lines marked with red arrows, increasing the depth of the cut until the board will bend right back on itself without tearing. Follow this procedure with all red arrow lines when dealing with parts on which they occur. Glue the appropriate windows and door in place, apply the two Nameboards over the printed ones and add the Wall Capping. Glue Base A to the back, flush along the bottom and at right angles to it, applying at the same time a Strengthening Bracket as shown.

ASSEMBLY INSTRUCTIONS FOR SUPERQUICK LOW RELIEF No. 1 (continued)

- 2 Separate "THE REGENT" Wall, leaving the white margin on the left attached and deal with the red arrow lines as above. Apply the Front B1, having first blackened the edges. Cut out and bend the Bay Window to shape, place in position and glue the tabs down firmly. Bend and glue the Base B3 and Top B4 into the Bay and apply its Roof. Bend the wall to shape, noting that the ground floor left hand corner is angled, and glue around Base B. Bend the Outer Doors inwards at right angles and glue the Inner Door against their back edges. Glue False Roof B5 in place a little below the top edge of the wall. Repair the cut in the side wall between the ground and upper floors with a paper strip glued across the cut, at the same time bringing the back corners into line. Apply Side B2. Lay the building on its back and fix the Guttering and Main Roof (flush at the back), Nameboard, Facia Cornice and Sun Blinds. Cut out Dormer Window, bend to shape and glue in place.
- 3 Separate "THE RED LION" Wall leaving the white margin on the right attached. Fold the Tabs C2 right back and glue down. The False Roof C3 will be seated later against the edges of these tabs. Proceed with construction as before but bend up and glue the Dormer Windows to the back of their frames after fixing False Roof C3 but before fixing the Main Roof. Glue the three buildings together where shown and fix Flat Roof A1 at the back of "NORWICH UNION" running in the slots and flush with the inner side walls of the other buildings. Support this roof with Strengthening Brackets. Apply the Chimneys, Steps and Wall Capping.